

escape™

a journey through sound



ESCAPE P9 TRAVEL CASE MANUAL

The Escape P9 travel case is produced from a strong & light-weight material known as "ABS/PC-Polycarbonate" which will accompany you on every journey with ease.

Limited Global Warranty

The travel case is covered by a 1-year limited warranty from the date of invoice. If a problem occurs with the Escape Travel Case and the problem is caused by manufacturing defects in material and workmanship, Escape bvba will, in its discretion, either fix or replace the product in accordance with the warranty terms and conditions stated herein.

The warranty provided for herein applies only to and extends for the lifetime of the first purchaser or gift recipient of the product. This warranty covers only manufacturing defects and does not cover any damage caused by misuse such as transporting inappropriate

objects, using the travel case as a chair or transporting children, accidents, abrasion, neglect, theft, exposure to extreme temperatures, solvents, acids, water, normal wear and tear or transport damage by airlines or freight forwarders.

If the travel case is damaged during transportation we ask you to take the matter up directly with your carrier of shipping agent. When transporting in your car, make sure that the P9 Travel Case is well protected and secured and cannot slide around. Incidental and direct or indirect damage of the content of the Escape Travel Case are not covered under warranty.

Safety Warning



To help prevent tip-over:

- Always place the unit on a firm, flat and level surface.
- Never allow children to climb or hang on the Escape P9 Travel Case.
- Do not put any heavy objects on top of the unit.

Instructions



Cable Holder Bag
(included in the P9 Travel Case)



Position of the P9
and handle



Position of the
Cable Holder Bag